

# Xtreme BOTS

## Safety Reminders

1. Safety glasses MUST be worn at all times in the pit area.
2. Always approach your bot from the safest angle, avoiding all weapons.
3. No sandals or open-toed shoes in the pit area or arena.
4. Test cages are for testing of fail-safes and weapons operations only. NO test driving in the test cage.
5. If any team member is determined to be willfully and repeatedly violating any safety procedures, the team member's team will forfeit ALL matches and may be required to leave the venue.

## Safe Power-Up/Power-Down Procedure

### Remember:

1. Do not position yourself in close proximity to any dangerous part of your bot while powering up and down.
2. Only one person from each team is allowed inside the arena while powering up or down a bot.

### Powering up your bot:

1. Remove safety covers but leave weapon locking pins in place.
2. Turn on receiver.
3. Turn on transmitter.
4. Turn on master power.
5. Turn on pneumatics or hydraulics if applicable.
6. Remove weapon locking pins.
7. Leave the arena.

Once all persons are safely outside the arena and instructed by a referee, you may give your bot a quick test to make sure all systems are working properly. Under no circumstances should a bot or weapon ever be driven or activated while a person is still inside the arena.

### Powering down your bot:

1. Make sure the bot is safely idle inside the arena, and make sure your transmitter is in a position where it will not be touched; then enter the arena.
2. Turn off pneumatics or hydraulics if applicable.
3. Turn off master power.
4. Turn off transmitter.
5. Turn off receiver.
6. Replace weapon locking pins and safety covers.
7. Remove bot from arena.

Questions? Email us at [info@xtremebots.org](mailto:info@xtremebots.org)